


# U914 MPX BOARD PW5686

TO BACK TERMINAL BOARD



IC001

MODE	PIH	Q
MONO	0.1	11.9
STEREO	0.8	11.9
BILINGUAL	11.8	0


IC002

MODE	PIH	Q
MONO	1.3	0.1
STEREO	6.0	0.2
BILINGUAL	3.7	11.4

IC003


MODE	PIH	Q
MONO	1.3	0.1
STEREO	6.0	0.2
BILINGUAL	3.7	11.4


# U501A SECAM CHROMA BOARD PW5631




U903A BACK TERMINAL BOARD PW5687-1


21	SHIELD	EARTH
20	VIDEO IN	1Vpp 2348
19	VIDEO OUT	1Vpp 2348
18	RAPID BLK	HS EARTH
17	VIDEO	EARTH
16	RAPID BLANKING	0:0-0.4V 1:1-1.3V
15	RED IN	0.7Vpp 2348
14	NC	
13	RED EARTH	
12	NC	
11	GREEN IN	0.7Vpp 2348
10	NC	
9	GREEN EARTH	
8	EXT. TV	1V0-2V EXT: 8.3 12V
7	BLUE IN	0.1Vpp 2348
6	AUDIO IN (L)	0.2-2Vrms
5	AUDIO EARTH	
4	AUDIO OUT (L)	0.2-2Vrms
3	AUDIO IN (R)	0.2-2Vrms
2	AUDIO OUT (R)	0.2-2Vrms




[illegible]



PW5685-1



# U902B PRE-SCALER BOARD PW5685-2



# U903B CRT DRIVE BOARD PW5687-2

